


# 3-POSITION SWITCH

## Connecting a 3-Position or 2-Position Light Switch to a PXPD WIRING HARNESS




### 3-POSITION SWITCH / CONNECTION DIAGRAM

#### Phoenix / Headlights & Halo Lights

Halo & Headlights (up)  
Off (center)  
Halo Only (down)



HL2 (Halo Lights)  
PWR (Zip-tied wire)  
HL2 (Halo Lights)



#### Precedent & Phantom / Headlights (No Halo)

Headlights (up)  
Off (center)  
Off (down)




HL1 (Head Lights)  
PWR (Zip-tied wire)  
Blank

**NOTE: The wiring remains the same for Precedent & Phantom, but will result in 2 OFF positions.**  
(There is an optional 2-position switch available)




## 3-POSITION SWITCH CONNECTIONS

### Phoenix / Phantom / Precedent

#### 3-Position Switch - Front / Back




#### 3-Position Switch - Connection Diagram



## 2-POSITION SWITCH CONNECTIONS

### Phantom & Precedent Only (Optional)

#### 2-Position Switch - Front / Back



#### 2-Position Switch - Connection Diagram

